


Back-Up Light

From Power Source System (See Page 62)



Service Hints

P1 Back-Up Light SW

2-1 : Closed with the shift lever in R position

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J12	44	P1	41 (2AZ-FE)	R8	45
P1	39 (3MZ-FE)	R7	45		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	29	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
4A	33	Cowl Wire and Passenger Side J/B (Right Side of Grove Box)
4I	32	

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	52	Cowl Wire and Floor No.2 Wire (Left Kick Panel)
IM1	54	Engine Wire and Cowl Wire (Right Kick Panel)

: GROUND POINTS

Code	See Page	Ground Points Location
BC	56	Left Side of Rear Cross Member