


Engine Immobilizer System



Service Hints

T14 Transponder Key Computer

- 1-Ground : Always approx. 12 volts
- 14-Ground : Always continuity
- 2-Ground : Approx. 12 volts with ignition SW at ON or ST position

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
D3	42	J16	43	T7	43
D7	44	J17	43	T14	43
E6	42	K4	43		
J6	43	T5	43		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	29	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
1G		
2A	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
3B	30	Instrument Panel Wire and Center J/B (Behind the Instrument Panel Center)
3F		
3K	31	
4A	33	Cowl Wire and Passenger Side J/B (Right Side of Grove Box)
4E		
4G		
4K	32	
4L		
4M		
4N		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	52	Cowl Wire and Floor No.2 Wire (Left Kick Panel)
IC3	52	Engine Room Main Wire and Cowl Wire (Left Cowl Side Panel)
IF3	52	Instrument Panel Wire and Cowl Wire (Right Side of Instrument Panel J/B)

: GROUND POINTS

Code	See Page	Ground Points Location
IB	52	Right Instrument Panel Brace
IC	52	Right Cowl Side Panel