


NAVIGATION ECU REPLACEMENT

6715T-01

HINT:


- COMPONENTS: See page [67-2](#)
- Installation is in the reverse order of removal.

1. REMOVE FRONT SEAT ASSEMBLY LH POWER SEAT (SEE PAGE [72-1 1](#)) MANUAL SEAT (SEE PAGE [72-19](#))




2. REMOVE NAVIGATION ECU COVER

- (a) Remove the 4 claws and the navigation ECU cover.



3. REMOVE NAVIGATION ECU W/BACKET

- (a) Disconnect the connector.
(b) Remove the 2 bolts and the navigation ECU w/ bracket.



4. REMOVE DISC PLAYER BRACKET

- (a) Remove the 4 screws and the disc player bracket.

5. REMOVE NAVIGATION ECU

6. INSTALL NAVIGATION ECU

HINT:

Perform the screen noise automatic adjustment when screen noise occurs (see page [05-1803](#)).

7. INSTALL FRONT SEAT ASSEMBLY LH POWER SEAT (SEE PAGE [72-1 1](#)) MANUAL SEAT (SEE PAGE [72-19](#))