


G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness

▽ : Location of Ground Points


[3MZ-FE]



○ : Location of Splice Points



Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
EA1	Engine Wire and Sensor Wire (Right Side of Cylinder Head)
EB1	Engine Wire and Engine Room Main Wire (Front Side of Engine Room R/B)
EB2	Engine Wire and Engine Room Main Wire (Front Side of Engine Room R/B)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness

▽ : Location of Ground Points


[2AZ-FE]



○ : Location of Splice Points




Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
EB1	Engine Wire and Engine Room Main Wire (Front Side of Engine Room R/B)
EB2	

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness



▽ : Location of Ground Points




Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
IA1	Cowl Wire and Floor No.2 Wire (Left Kick Panel)
IA2	
IB1	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IB2	
IC1	Engine Room Main Wire and Cowl Wire (Left Cowl Side Panel)
IC2	
IC3	
IC4	
IE1	Roof Wire and Cowl Wire (Near the Bottom of Left Front Pillar)
IF1	Instrument Panel Wire and Cowl Wire (Right Side of Instrument Panel J/B)
IF2	
IF3	
IG1	Instrument Panel Wire and Cowl Wire (Upper Portion of Right Instrument Panel Brace)

G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness



○ : Location of Splice Points



Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
IH1	Cowl Wire and A/C Sub No.2 Wire (Upper Portion of Right Instrument Panel Brace)
II1	Instrument Panel Wire and A/C Sub No.1 Wire (Upper Portion of Right Instrument Panel Brace)
IJ1	Instrument Panel Wire and A/C Sub No.3 Wire (Upper Portion of Right Instrument Panel Brace)
IK1	Engine Room Main Wire and Cowl Wire (Right Cowl Side Panel)
IK2	
IK3	
IK4	
IL1	Instrument Panel Wire and Cowl Wire (Upper Side of Passenger Side J/B)
IL2	
IM1	Engine Wire and Cowl Wire (Right Kick Panel)
IN1	Front Door RH Wire and Cowl Wire (Right Kick Panel)
IN2	
IO1	Cowl Wire and Floor Wire (Right Kick Panel)
IO2	
IP1	Instrument Panel Wire and Floor Wire (Left Side of Passenger Side J/B)
IR1	Instrument Panel Wire and Floor Wire (Under the Shift Lever)
IR2	


G ELECTRICAL WIRING ROUTING

□ : Location of Connector Joining Wire Harness and Wire Harness


▽ : Location of Ground Points



○ : Location of Splice Points



Connector Joining Wire Harness and Wire Harness




Code	Joining Wire Harness and Wire Harness (Connector Location)
BB1	Rear Door No.1 LH Wire and Floor No.2 Wire (Left Center Pillar)
BC1	Rear Door No.1 RH Wire and Floor Wire (Right Center Pillar)
BG1	Back Door No.1 Wire and Floor No.2 Wire (Rear Left of the Roof)
BG2	
BG3	
BH1	Floor No.2 Wire and Floor Wire (Near the Rear Side Marker Light RH)
BI1	Floor No.4 Wire and Fuel Tank Wire (Right Side of Rear Floor Crossmember)
BJ1	Floor Wire and Floor No.4 Wire (Right Side of Rear Floor Crossmember)
BK1	Roof No.2 Wire and Floor Wire (Right Rear Quarter Panel)
BK2	


G ELECTRICAL WIRING ROUTING

□ : Location of Connector Joining Wire Harness and Wire Harness


[w/ Power Seat]



[w/o Power Seat]



Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
BL1	Floor Wire and Front Seat RH Wire (Under the Front Passenger's Seat)
BM1	