


Your navigation system — — Quick reference



1 “DISPLAY” button

Push this button to display the “Display” screen. 110

2 “INFO” button

Push this button to display the “Information menu” screen. ii, 96, 101, 108, 109

3 Zoom out switch

Touch this switch to reduce the map scale. 8

4 “Mark” switch

Touch this switch to register the cursor position as a memory point. 6

5 “Route” switch

Touch this switch to change the route. 42, 44

6 “Map View” switch

Touch this switch to obtain information regarding the route to the destination and information about the POI (Points of Interest) on map screen. 49, 51, 52

7 “OFF” switch


Touch this switch to obtain a broader view, some of the switches on the screen are not displayed. They reappear by touching the “ON ►” switch. 89

8	Zoom in switch	Touch this switch to magnify the map scale. 8
9	Foot print map switch	Touch this switch to display the foot print map and the building information. 58
10	“MENU” button	Push this button to display the “Menu” screen. xii, 16, 61
11	Screen configuration switch	Touch this switch to change the screen mode. 53
12	“DEST” button	Push this button to display the “Destination” screen. x, 20
13	Distance and time to destination	Displays the distance and the estimated travel time to the destination. 57
14	“MAP” button	Push this button to repeat a voice guidance, cancel one touch scroll, start guidance and display the current position. 4, 5, 42

15	“GPS” mark (Global Positioning System)	Whenever your vehicle is receiving signals from the GPS, this mark is displayed. 9
16	Scale indicator	This figure indicates the map scale. 8
17	North-up or heading-up symbol	This symbol indicates a map view with north-up or heading-up. Touching this sym- bol changes the map orientation. 9



— “Destination” screen



To search for a destination, the switches below perform the following operations.

1 “Address” switch

You can input the house number and the street address by using the input keys.

..... 22

2 “POI Name” switch

You can select one of the many POIs (Points of Interest) that have been already stored in the system’s database.

..... 26

3 “POI Category” switch

You can select a destination from the POI category.

..... 29

4 “Previous” switch

You can select a destination from any of the last 99 previously set destinations and from the previous starting point.

..... 34

5 “Memory” switch

You can select the location from those registered as the “Memory points”. (To register memory points, see page 66.)

..... 33

6 “Emergency” switch

You can select one of the three categories of emergency service points that have been already stored in the system’s database.

..... 32

7 “Map” switch

You can select a destination simply by touching the location on the displayed map. 34

8 “Intersection” switch

You can enter the names of two intersecting streets. This is helpful if you do not know the specific street address of your destination but know the general vicinity. 35

9 “Freeway Ent./Exit” switch

You can enter the name of a freeway (interstate) entrance or exit. 36

10 “Phone #” switch

You can enter a destination by the telephone number. 37

11 “Coordinates” switch

You can set a destination using latitude and longitude coordinates. 37

12 Quick access switch

You can select one of 5 preset destinations directly. To use this function, it is necessary to set the “Attribute” for each memory point. (To register the “Quick Access”, see page 70.) 22

13 Home switch


You can select your own home without entering the address each time. To use this function, it is necessary to set the “Attribute” for the memory point. (To register the “Home”, see page 70.) 22

14 “Change” switch

To change the search area, touch this switch. 20



— “Menu” screen



The switches below perform the following operations.

1 “Map DVD” switch

Displays information regarding the disc version or covered area. 12

2 “Select User” switch

Enables recall of up to three memorized user setting patterns. 63

3 “Setup” switch

Enables various settings for the navigation system. 76

4 “My Places” switch

Enables changes to “Memory points” and “Areas to avoid”. 66

5 “Suspend Guidance” and “Resume Guidance” switch

Suspends or resumes the guidance. 62

6 “Volume” switch

Sets the volume of the voice guidance. 63