

DIAGNOSTIC TROUBLE CODE CHART

1. BODY ECU DIAGNOSTIC TROUBLE CODE

DTC Code	Lamp Code	Diagnostic Item	Diagnostic Result
B1200	Normal code	Normal	Normal
B1211	11	Power window regulator master switch assy (door ECU) communication stop	No communication from door ECU for more than 10 seconds
B1214	-	Communication bus +B battery system short	Communication circuit and +B battery system short
B1215	-	Communication bus (body ground) short	Communication bus and body ground short
B1241	41	Body ECU switch circuit diagnosis	Switch is ON or stuck
B1261	-	ECM communication stop	No communication from ECM for more than 10 seconds
B1262	62	Airconditioner amplifier assy (A/C ECU) communication stop	No communication from A/C ECU for more than 10 seconds
B1269	69	Theft warning ECU assy (theft deterrent ECU) communication stop	No communication from theft warning ECU for more than 10 seconds
B1271	-	Combination meter assy (meter ECU) communication stop	No communication from meter ECU for more than 10 seconds
B1273	73	Sliding roof drive gear sub-assy (sliding roof ECU) communication stop	No communication from sliding roof ECU for more then 10 seconds