

**SOUND QUALITY IS BAD IN ALL MODES (VOLUME IS TOO LOW)****INSPECTION PROCEDURE****1 ADJUST SOUND QUALITY**

(a) Adjust the sound quality.

(1) Operate the radio receiver assy to adjust the sound quality.

**OK: Malfunction disappears.**

**OK****BAD SOUND QUALITY****NG****2 COMPARE IT WITH ANOTHER VEHICLE OF SAME MODEL**

(a) Compare it with another vehicle of the same model.

(1) Compare it with the vehicle of the same type which does not have a trouble to see if there is any difference in the sound quality.

**OK: No difference is found.**

**OK****SETTING****NG**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE  
(SEE PAGE [05-1632](#) )**