


# TELEVISION DISPLAY ASSY REPLACEMENT


67164-01

**HINT:**

- COMPONENTS: See page [67-2](#)
- Installation is in the reverse order of removal.

**1. REMOVE TELEVISION BASE**

- (a) Release the 4 claws and remove the television base.

**2. REMOVE TELEVISION DISPLAY ASSY**

- (a) Disconnect the connector and remove the 4 nuts and the television display assy.