


\* 1 : 3MZ- FE  
\* 2 : 2AZ- FE



E 7  
Engine Control Module

# Starting and Ignition

## Service Hints

### I15 Ignition SW

7-6 : Closed with the ignition SW at ON or ST position

7-8 : Closed with the ignition SW at ST position

### P1 Park/Neutral Position SW

5-4 : Closed with the A/T shift lever in P or N position

### S1 (A), S2 (B) Starter

Points closed with the Park/Neutral position SW at P or N position and ignition SW at ST position

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
E7	42	I5	39 (3MZ-FE) 41 (2AZ-FE)	P1	39 (3MZ-FE) 41 (2AZ-FE)
F7	38 (3MZ-FE) 40 (2AZ-FE)	I6	39 (3MZ-FE)	S1	A 39 (3MZ-FE) 41 (2AZ-FE)
I2	39 (3MZ-FE) 41 (2AZ-FE)	I7	39 (3MZ-FE)	S2	B 39 (3MZ-FE) 41 (2AZ-FE)
I3	39 (3MZ-FE) 41 (2AZ-FE)	I15	43	S28	A 43
I4	39 (3MZ-FE) 41 (2AZ-FE)	J2	39 (3MZ-FE) 41 (2AZ-FE)	S29	B 43
		N1	39 (3MZ-FE) 41 (2AZ-FE)		

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	22	Engine Room R/B (Engine Compartment Left)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	29	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
1C		
1F	29	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
1G		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	48 (3MZ-FE) 50 (2AZ-FE)	Engine Wire and Engine Room Main Wire (Front Side of Engine Room R/B)
EB2	48 (3MZ-FE) 50 (2AZ-FE)	
IC1		
IC3	52	
		Engine Room Main Wire and Cowl Wire (Left Cowl Side Panel)

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	48 (3MZ-FE)	Left Side of Cylinder Head
EF	50 (2AZ-FE)	Left Side of Cylinder Block
EH	48 (3MZ-FE) 50 (2AZ-FE)	Under the Left Headlight

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E6	48 (3MZ-FE)	Engine Wire	E8	50 (2AZ-FE)	Engine Wire
E7	48 (3MZ-FE)		E9		
	50 (2AZ-FE)				

