


MAP DISC CANNOT BE INSERTED

INSPECTION PROCEDURE

1 CHECK MAP DISC



- (a) Check that the map disc is not deformed or cracked.
OK: No deformations or cracks appear on the map disc.

NG**REPLACE THE MAP DISC****OK**

2 CHECK NAVIGATION ECU

- (a) Check that the "PUSH" indicator near the disc slot comes on.
OK: It does not come on.

NG**PRESS THE EJECT SWITCH TO EJECT THE DISC****OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE [05-1778](#))**