


REAR WIPER MOTOR ASSY REPLACEMENT

660HR-01


HINT:

Installation is in the reverse order of removal.


1. **REMOVE RR WIPER ARM & BLADE ASSY**
 - (a) Remove the rear wiper arm cover.
 - (b) Remove the nut and the RR wiper arm & blade assy.
2. **REMOVE REAR WIPER MOTOR GROMMET**
3. **REMOVE ASSIST STRAP HOLE COVER (SEE PAGE 75-20)**
4. **REMOVE ASSIST STRAP ASSY RH (SEE PAGE 75-20)**
5. **REMOVE BACK DOOR TRIM PANEL ASSY (SEE PAGE 75-20)**



6. **REMOVE REAR WIPER MOTOR ASSY**
 - (a) Disconnect the connector.
 - (b) Remove the 3 bolts and the rear wiper motor assy.




7. **INSTALL REAR WIPER MOTOR ASSY**
 - (a) Install the rear wiper motor assy with the 3 bolts.
Torque: 5.5 N·m (56 kgf·cm, 48 in.-lbf)
 - (b) Connect the connector.




8. **INSTALL REAR WIPER MOTOR GROMMET**
 - (a) As shown in the illustration, install the rear wiper motor grommet with its position mark upside.

9. **INSTALL RR WIPER ARM & BLADE ASSY**
 - (a) Stop the rear wiper motor assy at the automatic stop position.



- (b) Scrape off the wiper arm serration with a round file or equivalent.
- (c) Clean the rear wiper pivot serration with a wire brush.



- (d) Install the RR wiper arm & blade assy in the position shown in the illustration.
- (e) Install the RR wiper arm & blade assy with the nut.
Torque: 5.5 N·m (56 kgf·cm, 48 in.·lbf)

HINT:

Hold down the arm hinge by hand in order to fasten the nut.

- (f) Install the rear wiper arm cover.
- (g) Operate the wiper while running water or washer fluid over the window, and check the wiping condition and that the rear wiper does not scrape against the body.