


TRANSMISSION CONTROL CABLE ASSY (ATM)

4005X-06


REPLACEMENT

1. REMOVE INSTRUMENT CLUSTER FINISH PANEL ASSY CENTER (SEE PAGE 71-10)
2. REMOVE FLOOR CARPET COVER CENTER RH (SEE PAGE 71-10)
3. REMOVE FLOOR CARPET COVER CENTER LH (SEE PAGE 71-10)
4. REMOVE BATTERY
5. REMOVE AIR CLEANER ASSY
6. REMOVE AIR CLEANER HOSE NO.1




7. REMOVE TRANSMISSION CONTROL CABLE ASSY


- (a) Remove the nut from the control shaft lever.
- (b) Disconnect the control cable from the control shaft lever.




- (c) Remove the clip and disconnect the control cable from the control cable bracket.




- (d) Disconnect the control cable from the control cable clamp.




- (e) Disconnect the cable end from the rod of the floor shift assy.



- (f) Remove the 2 nuts.




- (g) Remove the 3 bolts.
(h) Pull out the control cable from the body.




8. INSTALL TRANSMISSION CONTROL CABLE ASSY


- (a) Pull in the control cable to the body.
(b) Install the 3 bolts.
Torque: 4.9 N·m (50 kgf·cm, 43 in.-lbf)




- (c) Install the cable end, as shown in the illustration.
HINT:
Install it with the uneven surface facing up.




- (d) Install the control cable and 2 nuts.
Torque: 11.8 N·m (122 kgf·cm, 9 ft·lbf)



- (e) Connect the control cable to the control cable clamp.



- (f) Temporarily install the control cable to the control shaft lever with nuts.



- (g) Install the control cable and clip to the bracket.

9. INSTALL AIR CLEANER ASSY

10. ADJUST SHIFT LEVER POSITION (SEE PAGE 40-71)

11. INSPECT SHIFT LEVER POSITION (SEE PAGE 40-71)