

OIL W/HOSE COOLER ASSY (U151E/U151F)

4012F-02


REPLACEMENT

1. REMOVE FRONT BUMPER COVER (SEE PAGE 76-2)

2. DRAIN AUTOMATIC TRANSAXLE FLUID


- (a) Remove the drain plug and gasket, and drain ATF.
- (b) Install a new gasket and the drain plug.

Torque: 49 N·m (500 kgf·cm, 36 ft·lbf)



3. REMOVE OIL COOLER ASSY

- (a) Disconnect the 2 oil cooler hoses.
- (b) Remove the bolt, nut and oil cooler assy.



4. INSTALL OIL COOLER ASSY

- (a) Install the oil cooler assy, bolt A and nut B.

HINT:

After temporarily tightening the bolt A, fully tighten in order of the nut B, bolt A.

Torque: 7.0 N·m (71 kgf·cm, 62 in·lbf)

- (b) Connect the 2 oil cooler hoses.

5. INSTALL FRONT BUMPER COVER (SEE PAGE 76-2)

6. ADD AUTOMATIC TRANSAXLE FLUID

7. INSPECT AUTOMATIC TRANSAXLE FLUID (SEE PAGE 40-2)