

DTC	B0110/43	SHORT IN SIDE SQUIB (RH) CIRCUIT
-----	----------	----------------------------------

CIRCUIT DESCRIPTION


The side squib RH circuit consists of the airbag sensor assy center and the separate type front seat back assy (side squib RH).

The circuit instructs the SRS to deploy when deployment conditions are met.

DTC B0110/43 is recorded when a short circuit is detected in the side squib RH circuit.


DTC No.	DTC Detecting Condition	Trouble Area
B0110/43	<ul style="list-style-type: none"> • Short circuit between SFR+ wire harness and SFR- wire harness of side squib RH • Side squib (RH) malfunction • Airbag sensor assy center malfunction 	<ul style="list-style-type: none"> • Separate type front seat back assy (Side squib RH) • Airbag sensor assy center • Floor wire

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK FLOOR WIRE(SIDE SQUIB RH CIRCUIT)




- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Disconnect the connectors from the airbag sensor assy center and the separate type front seat back assy (side squib RH).
- Release the activation prevention mechanism built into connector "B" (see page 05-1207).
- Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
S19-1 (SFR+) - S19-2 (SFR-)	Always	1 MΩ or Higher

NG**REPAIR OR REPLACE FLOOR WIRE****OK**

2 CHECK AIR BAG SENSOR ASSY CENTER




- Connect the connector to the airbag sensor assy center.
- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the DTCs stored in memory (see page 05-1215).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check the DTCs (see page 05-1215).

OK:**DTC B0110/43 is not output.****HINT:**

Codes other than code B0110/43 may be output at this time, but they are not related to this check.

NG**REPLACE AIR BAG SENSOR ASSY CENTER (SEE PAGE 60-53)****OK**

3 CHECK SEPARATE TYPE FRONT SEAT BACK ASSY(SIDE SQUIB RH)



- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Connect the connector to the separate type front seat back assy (side squib RH).
- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the DTCs stored in memory (see page 05-1215).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check the DTCs (see page 05-1215).

OK:

DTC B0110/43 is not output.

HINT:

Codes other than code B0110/43 may be output at this time, but they are not related to this check.

NG

REPLACE SEPARATE TYPE FRONT SEAT BACK ASSY(SEE PAGE 72-1 1, 72-19)

OK

USE SIMULATION METHOD TO CHECK

HINT:

- Before performing the simulation method, check that the airbag sensor assy center is in check mode (see page 05-1218).
- Perform the simulation method by selecting the check mode with the hand-held tester (see page 05-1218).
- After selecting the check mode, perform the simulation method by wiggling each connector of the air-bag system or driving the vehicle on a city or rough road (see page 05-1218).