


ECM (2AZ-FE)

REPLACEMENT


100IQ-02

1. DISCONNECT BATTERY NEGATIVE TERMINAL
2. REMOVE FRONT DOOR SCUFF PLATE RH (See page 71-10)
3. REMOVE COWL SIDE TRIM SUB-ASSY RH (See page 71-10)
4. REMOVE GLOVE COMPARTMENT DOOR ASSY (See page 71-10)
5. REMOVE INSTRUMENT PANEL FINISH PANEL LOWER NO.2 (See page 71-10)




6. REMOVE ECM

- (a) Remove the 2 wire harness clamps.
- (b) Disconnect the 5 ECM connectors.
- (c) Remove the 2 nuts and ECM.



7. REMOVE ECM BRACKET NO. 1

- (a) Remove the 2 screws and ECM bracket.




8. REMOVE ECM BRACKET NO. 2

- (a) Remove the 2 screws and ECM bracket.


9. INSTALL ECM BRACKET NO. 2

- (a) Install the ECM bracket with the 2 screws.



10. INSTALL ECM BRACKET NO. 1

- (a) Install the ECM bracket with the 2 screws.

**11. INSTALL ECM**

- (a) Install the 2 wire harness clamps.
- (b) Connect the 5 ECM connectors.
- (c) Install the ECM with the 2 nuts.

Torque: 5.5 N·m (56 kgf·cm, 49 in·lbf)

- 12. INSTALL INSTRUMENT PANEL FINISH PANEL LOWER NO.2 (See page 71-10)**
- 13. INSTALL GLOVE COMPARTMENT DOOR ASSY (See page 71-10)**
- 14. INSTALL COWL SIDE TRIM SUB-ASSY RH (See page 71-10)**
- 15. INSTALL FRONT DOOR SCUFF PLATE RH (See page 71-10)**
- 16. CONNECT BATTERY NEGATIVE TERMINAL**