


DTC	P2A00	A/F SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 1)
------------	--------------	---

CIRCUIT DESCRIPTION

Refer to DTC P2195 on page [05-269](#) .

DTC No.	DTC Detection Condition	Trouble Area
P2A00	In conditions (a), (b) and (c), when A/F sensor output voltage change value is below regular value against fuel trim change value, ECM judges that A/F sensor circuit has slow response: (2 trip detection logic) (a) Engine is warmed up (b) Engine speed 1,400 rpm or more (c) Vehicle speed 60 to 120 km/h (37 to 74 mph)	<ul style="list-style-type: none"> • Open or short in A/F sensor circuit • A/F sensor • A/F sensor heater • EFI relay • Open or short in A/F sensor and EFI relay circuits • Air induction system • Fuel pressure • Injector • PCV hose connection • ECM

MONITOR DESCRIPTION



The Air-Fuel ratio (A/F) sensor varies its output voltage in proportion to the air-fuel ratio. Based on the output voltage, the ECM determines if the air-fuel ratio is RICH or LEAN and adjusts the stoichiometric air-fuel ratio. The ECM also checks the fuel injection volume compensation value to check if the A/F sensor is deteriorating or not. A/F sensor response deterioration is determined by the ratio of the A/F sensor output voltage variation and fuel trim variation.

MONITOR STRATEGY

Related DTCs	P2A00: A/F sensor slow response
Required sensors / components (Main)	A/F sensor
Required sensors / components (Related)	Vehicle speed sensor (VSS) and crankshaft position (CKP) sensor
Frequency of operation	Once per driving cycle
Duration	60 sec.
MIL operation	2 driving cycles
Sequence of operation	None

TYPICAL ENABLING CONDITIONS

The monitor will run whenever these DTCs are not present	See page 05-16
Engine condition	Running
Time after engine start	120 sec. or more
Fuel system status	Closed Loop
A/F sensor status	Activated
Idle	OFF
Time after idle OFF	2 sec. or more
Engine RPM	1,400 to 3,200 rpm
Vehicle speed	60 to 120 km/h (37.5 to 75 mph)
Fuel cut	OFF
Time after fuel cut is OFF	2 sec. or more
Driving for 20 sec. or more	40 km/h (25 mph) or more and 900 rpm or more

TYPICAL MALFUNCTION THRESHOLDS

Response rate deterioration level	8 or more
-----------------------------------	-----------

MONITOR RESULT

Refer to page [05-24](#) for detailed information.

The test value and test limit information are described as shown in the following table. Check the monitor result and test values after performing the monitor drive pattern (see page [05-26](#)).

- TID (Test Identification Data) is assigned to each emissions-related component.
- TLT (Test Limit Type):
If TLT is 0, the component is malfunctioning when the test value is higher than the test limit.
If TLT is 1, the component is malfunctioning when the test value is lower than the test limit.
- CID (Component Identification Data) is assigned to each test value.
- Unit Conversion is used to calculate the test value indicated on generic OBD II scan tools.

TID \$06: A/F sensor

TLT	CID	Unit Conversion	Description of Test Data	Description of Test Limit
0	\$01	Multiply by 0.000244 (no dimension)	Parameter for identify A/F sensor response rate	Malfunction threshold for A/F sensor deterioration

WIRING DIAGRAM

Refer to DTC P2195 on page [05-269](#) .

INSPECTION PROCEDURE

HINT:

Hand-held tester only:

The malfunctioning area can be found by the ACTIVE TEST A/F CONTROL operation. The A/F CONTROL operation can determine if the A/F sensor, heated oxygen sensor or other suspected trouble areas are malfunctioning or not.

(a) Perform the ACTIVE TEST A/F CONTROL operation.

HINT:

The A/F CONTROL operation lowers the injection volume by 12.5% or increases the injection volume by 25%.

- (1) Connect the hand-held tester to the DLC3 on the vehicle.
- (2) Turn the ignition switch ON.
- (3) Warm up the engine by running the engine at 2,500 rpm for approximately 90 seconds.
- (4) Enter the following menus: DIAGNOSIS / ENHANCED OBD II / ACTIVE TEST / A/F CONTROL.
- (5) Perform the A/F CONTROL operation with the engine idling (press the right or left button).

Result:

A/F sensor reacts in accordance with increase and decrease of injection volume:

+25 % → RICH output: Less than 3.0 V

-12.5 % → LEAN output: More than 3.35 V













































Heated oxygen sensor reacts in accordance with increase and decrease of injection volume:

+25 % → RICH output: More than 0.55 V

-12.5 % → LEAN output: Less than 0.4 V

NOTICE:

The A/F sensor output has a few seconds of delay and the heated oxygen sensor output has about 20 seconds of delay at maximum.

	Output voltage of A/F sensor (sensor 1)	Output voltage of heated oxygen sensor (sensor 2)	Main suspect trouble area
Case 1	Injection volume +25 %   -12.5 %   Output voltage More than 3.35 V  OK Less than 3.0 V 	Injection volume +25 %   -12.5 %   Output voltage More than 0.55 V  OK Less than 0.4V 	—
Case 2	Injection volume +25 %   -12.5 %   Output voltage Almost No reaction  NG	Injection volume +25 %   -12.5 %   Output voltage More than 0.55 V  OK Less than 0.4V 	A/F sensor (A/F sensor, heater, A/F sensor circuit)
Case 3	Injection volume +25 %   -12.5 %   Output voltage More than 3.35 V  OK Less than 3.0V 	Injection volume +25 %   -12.5 %   Output voltage Almost No reaction  NG	Heated oxygen sensor (heated oxygen sensor, heater, heated oxygen sensor circuit)
Case 4	Injection volume +25 %   -12.5 %   Output voltage Almost No reaction  NG	Injection volume +25 %   -12.5 %   Output voltage Almost No reaction  NG	Extremely rich or lean actual air-fuel ratio (Injector, fuel pressure, gas leakage in exhaust system, etc.)

The following A/F CONTROL procedure enables a technician to check and graph the voltage outputs of both the A/F sensor and the heated oxygen sensor.

For displaying the graph, enter "ACTIVE TEST / A/F CONTROL / USER DATA", select "AFS B1S1 and O2S B1S2" by pressing "YES" and push "ENTER". Then press "F4".

HINT:

- DTC P2A00 may be also detected, when the air fuel ratio is stuck rich or lean.
- A low A/F sensor voltage could be caused by a RICH air-fuel mixture. Check for conditions that would cause the engine to run with a RICH air-fuel mixture.
- A high A/F sensor voltage could be caused by a LEAN air-fuel mixture. Check for conditions that would cause the engine to run with a LEAN air-fuel mixture.
- Read freeze frame data using the hand-held tester or the OBD II scan tool. Freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, and other data from the time the malfunction occurred.

1 CHECK OTHER DTC OUTPUT (IN ADDITION TO A/F SENSOR DTC)

- (a) Read the DTC using the hand-held tester or the OBD II scan tool.

Result:

Display	Proceed to
Only P2A00 is output	A
P2A00 and other codes is output	B

HINT:

If any other codes besides P2A00 is output, perform the troubleshoot on that DTC before.

B

GO TO RELEVANT DTC CHART
(See page 05-48)

A

2 READ VALUE OF OBD II SCAN TOOL OR HAND-HELD TESTER (OUTPUT VOLTAGE OF A/F SENSOR)

- (a) Connect the hand-held tester or the OBD II scan tool to the DLC3.
- (b) Warm up the A/F sensor (bank 1 sensor 1) by running the engine at 2,500 rpm for approximately 90 seconds.
- (c) Read the A/F sensor voltage output on the the hand-held tester or OBD II scan tool.
- (d) Hand-held tester only:
On the hand-held tester, enter the following menus: DIAGNOSIS / ENHANCED OBD II / SNAPSHOT / MANUAL SNAPSHOT / USER DATA. Read the values.
- (e) Select "AFS B1 S1 / ENGINE SPD" and press YES.
- (f) Monitor the A/F sensor voltage carefully.
- (g) Check the A/F sensor voltage output under the following conditions:
- (1) Allow the engine to idle for 30 seconds.
 - (2) Run the engine at approximately 2,500 rpm. Do not suddenly change the rpm.
 - (3) Raise the engine speed to 4,000 rpm and quickly release the accelerator pedal so that the throttle is fully closed.


Standard:**Condition (1) and (2)**

Voltage change of 3.3 V (0.66 V)* (between approximately 3.1 to 3.5 V) as shown in the illustration.

Condition (3)

A/F sensor voltage increases to 3.8 V (0.76 V)* or more when fuel is cut during engine deceleration as shown in the illustration.

***: Voltage when using the OBD II scan tool.**

**HINT:**

- Whenever the A/F sensor output voltage remains at approximately 3.3 V (0.660 V)* (see "Malfunction Condition" graphic) under any condition as well as the above conditions, the A/F sensor may have an open circuit. This will happen also when the A/F sensor heater has an open circuit.
- Whenever the A/F sensor output voltage remains at a certain value of approximately 3.8 V (0.76 V)* or more, or 2.8 V (0.56 V)* or less (see "Malfunction Condition" graphic) under any condition as well as the above conditions, the A/F sensor may have a short circuit.
- The ECM will stop fuel injection (fuel is cut) during engine deceleration. This will cause a LEAN condition and should result in a momentary increase in the A/F sensor output voltage.
- The ECM must establish a closed throttle position learned value to perform fuel cut. If the battery terminal has been disconnected, the vehicle must be driven over 10 mph (16 km/h) to allow the ECM to learn the closed throttle position.
- When the vehicle is driven:
The output voltage of the A/F sensor may be below 2.8 V (0.76 V)* during fuel enrichment. For the vehicle, this translates to a sudden increase in speed with the accelerator pedal fully depressed when trying to overtake another vehicle. The A/F sensor is functioning normally.
- The A/F sensor is a current output element, and therefore the current is converted into voltage inside the ECM. If measuring voltage at connectors of the A/F sensor or ECM, you will observe a constant voltage.


*: Voltage when using the OBD II scan tool.

OK

Go to step 14

NG

3 INSPECT AIR FUEL RATIO SENSOR (HEATER RESISTANCE)



- (a) Disconnect the A6 A/F sensor connector.
- (b) Measure the resistance of the A/F sensor terminals.


Standard:

Tester Connection	Condition	Specified Condition
1 (HT) - 2 (+B)	20°C (68°F)	1.8 to 3.4 Ω
1 (HT) - 4 (AF-)	-	10 kΩ or higher

NG REPLACE AIR FUEL RATIO SENSOR

OK

4 INSPECT RELAY (EFI)



- (a) Remove the EFI relay from the engine room J/B.
- (b) Measure the resistance of the EFI relay.

Standard:


Tester Connection	Specified Condition
3 - 5	10 kΩ or higher
3 - 5	Below 1 Ω (when battery voltage is applied to terminals 1 and 2)

NG REPLACE RELAY


OK

5 CHECK WIRE HARNESS (A/F SENSOR - ECM)

Wire Harness Side



E8
ECM



A76787
A81695

A86849


(a) Check the wire harness between the ECM and A/F sensor.

- (1) Disconnect the A6 A/F sensor connector.
- (2) Disconnect the E8 ECM connector.
- (3) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
A6-3 (AF+) - E8-23 (A1A+) A6-4 (AF-) - E8-31 (A1A-) A6-1 (HT) - E8-5 (HA1A)	Below 1 Ω
A6-3 (AF+) or A1A+ (E8-23) - Body ground A6-4 (AF-) or A1A- (E8-31) - Body ground A6-1 (HT) or HA1A (E8-5) - Body ground	10 k Ω or higher

Reference



P

A90346

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

6 CHECK AIR INDUCTION SYSTEM

(a) Check for vacuum leaks in the air induction system.

OK: There is no leak in the air induction system.

NG

REPAIR OR REPLACE AIR INDUCTION SYSTEM

OK

7 CHECK CONNECTION OF PCV HOSE

OK: PCV hose is connected correctly and PCV hose has no damage.

NG

REPAIR OR REPLACE PCV HOSE

OK

8 CHECK FUEL PRESSURE (See page 11-4)

- (a) Check fuel pressure (high or low fuel pressure).

Standard:

Item	Specified Condition
Fuel pressure	304 to 343 kPa (3.1 to 3.5 kgf/cm ² , 44 to 55 psi)

NG

REPAIR OR REPLACE FUEL SYSTEM

OK

9 INSPECT FUEL INJECTOR ASSY (See page 11-7)

- (a) Check injector injection (high or low fuel injection quantity or poor injection pattern).

Standard:

Injection Volume	Difference Between Each Injector
76 to 91 cm ³ (4.6 to 5.5cu in.) / 15 seconds	15 cm ³ (0.9 cu in.) or less

NG

REPLACE FUEL INJECTOR ASSY
(See page 11-10)

OK

10 REPLACE AIR FUEL RATIO SENSOR

GO

11 PERFORM CONFIRMATION DRIVING PATTERN (See page 05-269)

HINT:

Clear all DTCs prior to performing the confirmation driving pattern (see page 05-269).

GO

12 READ OUTPUT DTC (A/F SENSOR DTC OUTPUT AGAIN)

(a) Read the DTC using the hand-held tester or the OBD II scan tool.

Result:

Display	Proceed to
DTC P2A00 is not output	A
DTC P2A00 is output	B

B

**REPLACE ECM (See page 10-9) AND PERFORM
CONFIRMATION DRIVING PATTERN
(See page 05-269)**

A

13 CONFIRM IF VEHICLE HAS RUN OUT OF FUEL IN PAST

NO

**CHECK FOR INTERMITTENT PROBLEMS
(See page 05-9)**

YES

DTC IS CAUSED BY RUNNING OUT OF FUEL

14 PERFORM CONFIRMATION DRIVING PATTERN (See page 05-269)

HINT:

Clear all DTCs prior to performing the confirmation driving pattern (see page 05-269).

GO

15 READ OUTPUT DTC (A/F SENSOR DTC OUTPUT AGAIN)

(a) Read the DTC using the hand-held tester or the OBD II scan tool.

Result:

Display	Proceed to
DTC P2A00 is output	A
DTC P2A00 is not output	B

B

Go to step 19

A

16 REPLACE AIR FUEL RATIO SENSOR

GO

17 PERFORM CONFIRMATION DRIVING PATTERN (See page 05-269)

HINT:

Clear all DTCs prior to performing the confirmation driving pattern (see page 05-269).

GO**18 READ OUTPUT DTC (A/F SENSOR DTC OUTPUT AGAIN)**

(a) Read the DTC using the hand-held tester or the OBD II scan tool.

Result:

Display	Proceed to
DTC P2A00 is not output	A
DTC P2A00 is output	B

B**REPLACE ECM (See page 10-9) AND PERFORM
CONFIRMATION DRIVING PATTERN (See page
05-269)****A****19 CONFIRM IF VEHICLE HAS RUN OUT OF FUEL IN PAST**

OK: Vehicle has run out of fuel in past.

NO**CHECK FOR INTERMITTENT PROBLEMS
(See page 05-9)****YES****DTC IS CAUSED BY RUNNING OUT OF FUEL**