

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Engine does not crank (does not start)	1. Starter 2. STARTER relay 3. PNP switch	19-12 19-12 40-6
No initial combustion (does not start)	1. ECM power source circuit 2. Fuel pump control circuit 3. ECM	05-312 05-349 01-36
No complete combustion (does not start)	1. Fuel pump control circuit	05-349
Difficult to start (engine cranks normally)	1. Starter signal circuit 2. Fuel pump control circuit 3. Compression	05-235 05-349 14-1
Difficult to start with cold engine	1. Starter signal circuit 2. Fuel pump control circuit	05-235 05-349
Difficult to start with hot engine	1. Starter signal circuit 2. Fuel pump control circuit	05-235 05-349
High engine idle speed (poor idling)	1. A/C signal circuit (Compressor circuit) 2. ECM power source circuit	05-1 190 05-312
Low engine idle speed (poor idling)	1. A/C signal circuit (Compressor circuit) 2. Fuel pump control circuit	05-1 190 05-349
Rough idling (poor idling)	1. Compression 2. Fuel pump control circuit	14-1 05-349
Hunting (poor idling)	1. ECM power source circuit 2. Fuel pump control circuit	05-312 05-349
Hesitation/Poor acceleration (poor driveability)	1. Fuel pump control circuit 2. A/T faulty	05-349 05-904
Surging (poor driveability)	1. Fuel pump control circuit	05-349
Engine stalls soon after starting	1. Fuel pump control circuit	05-349
Engine stalls during A/C operation	1. A/C signal circuit (Compressor circuit) 2. ECM	05-1 190 01-36
Unable to refuel/Difficult to refuel	1. ORVR system	—