



OVERHAUL

1. PRECAUTION (W/ SIDE AIRBAG) (SEE PAGE 60-1)
2. DISCONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 60-1)
3. REMOVE INSTRUMENT PANEL FINISH PANEL SUB-ASSY LOWER (SEE PAGE 71-10)
4. REMOVE INSTRUMENT PNL INSERT SUB-ASSY LWR LH (SEE PAGE 71-10)
5. REMOVE INSTRUMENT CLUSTER FINISH PANEL ASSY CENTER (SEE PAGE 71-10)
6. REMOVE FLOOR CARPET COVER CENTER RH (SEE PAGE 71-10)
7. REMOVE FLOOR CARPET COVER CENTER LH (SEE PAGE 71-10)
8. REMOVE FRONT SEAT ASSEMBLY RH
9. REMOVE FRONT SEAT ASSEMBLY LH (SEE PAGE 72-11, 72-19)
10. REMOVE CONSOLE BOX ASSY (SEE PAGE 71-10)
11. DISCONNECT TURN SIGNAL FLASHER ASSY
12. REMOVE FR FLOOR FOOTREST
 - (a) Remove the front floor footrest from the floor.




13. REMOVE PARKING BRAKE CONTROL PEDAL ASSY


- (a) Disconnect the connectors.
- (b) Remove the 2 nuts.
- (c) Separate the instrument panel junction block assy.
- (d) Release the parking brake pedal to the original position.
- (e) Remove the 2 bolts and nuts, and separate the parking brake cable assy No.1 from the floor.



- (f) Remove the parking brake cable assy No.1 from the parking brake equalizer.
- (g) Disconnect the parking brake switch connector.
- (h) Remove the 3 nuts and separate the instrument panel junction block assy w/ bracket from the body.
- (i) Remove the 3 nuts and parking brake control pedal assy.



- 14. REMOVE PARKING BRAKE CABLE ASSY NO.1 (SEE PAGE 33-10)**
- 15. REMOVE PARKING BRAKE SWITCH ASSY**
 - (a) Remove the screw and parking brake switch assy.
- 16. REMOVE PARKING PEDAL PAD**
 - (a) Remove the parking pedal pad.
- 17. INSTALL PARKING PEDAL PAD**
 - (a) Install the parking pedal pad.
- 18. INSTALL PARKING BRAKE SWITCH ASSY**
 - (a) Install the parking brake switch assy with the screw.
- 19. INSTALL PARKING BRAKE CABLE ASSY NO.1 (SEE PAGE 33-10)**



20. INSTALL PARKING BRAKE CONTROL PEDAL ASSY

- (a) Install the parking brake control pedal assy with the 3 nuts.

Torque: 39 N·m (400 kgf·cm, 29 ft·lbf)

- (b) Connect the parking brake switch connector.
 (c) Connect the instrument panel junction block assy w/ bracket with the 3 nuts.


- (d) Attach the parking brake cable assy No.1 to the parking brake equalizer and slide boot stopper of No.1 cable should be inserted into groove of T-Metal fitting.

- (e) Install the parking brake cable assy No.1 with the 2 bolts and 2 nuts.

Torque:


Bolt: 8.5 N·m (87 kgf·cm, 75 in·lbf)

Nut: 6.0 N·m (61 kgf·cm, 53 in·lbf)



- (f) Install the instrument panel junction block assy with the 2 nuts.

Torque: 7.3 N·m (74 kgf·cm, 65 in·lbf)



- (g) Connect the connectors.

21. INSTALL FR FLOOR FOOTREST

- (a) Install the front floor footrest on the floor.

22. INSTALL FRONT SEAT ASSEMBLY RH

23. INSTALL FRONT SEAT ASSEMBLY LH (SEE PAGE 72-11, 72-19)

24. REMOVE REAR WHEEL

25. ADJUST PARKING BRAKE SHOE CLEARANCE (SEE PAGE 33-19)

26. INSTALL REAR WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

27. INSPECT PARKING BRAKE PEDAL TRAVEL (SEE PAGE 33-2)

28. ADJUST PARKING BRAKE PEDAL TRAVEL (SEE PAGE 33-2)

29. CONNECT BATTERY NEGATIVE TERMINAL

30. INSPECT SRS WARNING LIGHT (W/ SIDE AIRBAG) (SEE PAGE 05-1207)