

## PRE-CHECK

### 1. CHECK USING HAND-HELD TESTER

- (a) Connect the hand-held tester to the DLC3.
- (b) Select the DATA LIST mode on the hand-held tester.

#### Sliding Roof ECU

Item	Switch condition	Standard value
OPEN SW	Pressed→Unpressed	ON/OFF
CLOSE SW	Pressed→Unpressed	ON/OFF
Position detection SW 1	Do sliding and tilting operation	ON/OFF
Position detection SW 2	Do sliding and tilting operation	ON/OFF
Hall IC condition	Do sliding and tiling operation	Normal/Abnormal
Hall IC out put	Do sliding and tiling operation	Lo/Hi
IG	Ignition Switch ON→OFF	ON/OFF
IG line signal	Ignition Switch ON→OFF	ON/OFF
Operation possible after key-OFF	Ignition Switch ON→OFF	ON/OFF

- (c) The active test will indicate if the part is normal or malfunctioning.

#### Sliding Roof ECU

Item	Condition
Sliding Roof	CLOSE/UP
Sliding Roof	OPEN/DOWN