

A REMOTE CONTROL SYSTEM DOES NOT OPERATE

INSPECTION PROCEDURE

1 CHECK BATTERY(SWITCH & VOLUME ASSY)

(a) Check battery.

(1) Check that the dry-cell battery used for the switch & volume assy is not dead.

Standard: It is not dead


NG

BATTERY IS DEAD

OK

2 CLEAN THE INFRARED RAY EMITTED PORTION

Infrared Ray Emitted Portion



(a) Clean the infrared ray emitted portion.

(1) Clean the infrared ray emitted portion on the television display assy.

(2) Check whether the same malfunction occurs.

Standard: The function returns to normal.

NG

**PROCEED TO NEXT CIRCUIT INSPECTION
SHOWN IN PROBLEM SYMPTOMS TABLE
(See page 05-1704)**

OK

NORMAL