



**Service Hints****FOG LIGHT Relay**

3-5 : Closed with the light control SW at HEAD position, dimmer SW at LOW position and fog light SW on

 : **PARTS LOCATION**

Code		See Page	Code	See Page	Code	See Page
B9	A	<a href="#">42</a>	F1	<a href="#">38 (3MZ-FE)</a>	J1	<a href="#">39 (3MZ-FE)</a>
B10	B	<a href="#">42</a>		<a href="#">40 (2AZ-FE)</a>		<a href="#">41 (2AZ-FE)</a>
B12	D	<a href="#">42</a>	F2	<a href="#">38 (3MZ-FE)</a>	J3	<a href="#">39 (3MZ-FE)</a>
C13		<a href="#">42</a>		<a href="#">40 (2AZ-FE)</a>		<a href="#">41 (2AZ-FE)</a>

 : **JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	<a href="#">29</a>	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
1G	<a href="#">29</a>	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
1H		
1J	<a href="#">28</a>	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
1K		
2A	<a href="#">27</a>	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
3A	<a href="#">30</a>	Instrument Panel Wire and Center J/B (Behind the Instrument Panel Center)
3B		

 : **CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC3	<a href="#">52</a>	Engine Room Main Wire and Cowl Wire (Left Cowl Side Panel)

 : **GROUND POINTS**

Code	See Page	Ground Points Location
EA	<a href="#">48 (3MZ-FE)</a>	Right Front Fender Apron
	<a href="#">50 (2AZ-FE)</a>	
EG	<a href="#">48 (3MZ-FE)</a>	Under the Left Headlight
	<a href="#">50 (2AZ-FE)</a>	
IA	<a href="#">52</a>	Left Cowl Side Panel

 : **SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E15	<a href="#">48 (3MZ-FE)</a>	Engine Room Main Wire	E15	<a href="#">50 (2AZ-FE)</a>	Engine Room Main Wire