

<b>DTC</b>	<b>B2795</b>	<b>UNMATCHED KEY CODE</b>
------------	--------------	---------------------------

## CIRCUIT DESCRIPTION

This DTC is output when a key with a key code that has not been registered in the ECU is inserted into the ignition key cylinder.

DTC No.	DTC Detection Condition	Trouble Area
B2795	Key with unregistered key code is inserted	• Key

## INSPECTION PROCEDURE

<b>1</b>	<b>DELETE DTC AND INSERT ALL PRESENTLY AVAILABLE KEYS TO CHECK WHETHER ENGINE STARTS OR NOT</b>
----------	---

**OK**

**NO PROBLEM  
(BECAUSE OF KEY RE-REGISTRATION)**

**NG**

**REPLACE KEY THAT DOES NOT START ENGINE**