

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Engine does not crank (does not start)	1. Starter 2. Starter relay 3. PNP switch	19-36 19-36 40-11
No initial combustion (does not start)	1. ECM power source circuit 2. Fuel pump control circuit 3. ECM	05-674 05-717 01-36
No complete combustion (does not start)	1. Fuel pump control circuit	05-717
Difficult to start (engine cranks normally)	1. Starter signal circuit 2. Fuel pump control circuit 3. Compression	05-595 05-717 14-121
Difficult to start with cold engine	1. Starter signal circuit 2. Fuel pump control circuit	05-595 05-717
Difficult to start with hot engine	1. Starter signal circuit 2. Fuel pump control circuit	05-595 05-717
High engine idle speed (poor idling)	1. A/C signal circuit (Compressor circuit) 2. ECM power source circuit	05-1190 05-674
Low engine idle speed (poor idling)	1. A/C signal circuit (Compressor circuit) 2. Fuel pump control circuit	05-1190 05-717
Rough idling (poor idling)	1. Compression 2. Fuel pump control circuit	14-121 05-717
Hunting (poor idling)	1. ECM power source circuit 2. Fuel pump control circuit	05-674 05-717
Hesitation/Poor acceleration (poor driveability)	1. Fuel pump control circuit 2. A/T faulty	05-717 05-1016
Surging (poor driveability)	1. Fuel pump control circuit	05-717
Engine stalls soon after starting	1. Fuel pump control circuit	05-717
Engine stalls during A/C operation	1. A/C signal circuit (Compressor circuit) 2. ECM	05-1190 01-36
Unable to refuel/Difficult to refuel	1. ORVR system	-