


CAMSHAFT POSITION SENSOR (2AZ-FE) REPLACEMENT

18094-02

HINT:

A bolt without a torque specification is shown in the standard bolt chart (see page 03-2).

1. REMOVE AIR CLEANER ASSY (See page 14-24)



2. REMOVE CAMSHAFT POSITION SENSOR

- (a) Disconnect the sensor connector.
- (b) Remove the bolt and sensor.

3. INSTALL CAMSHAFT POSITION SENSOR

- (a) Apply a light coat of engine oil to a new O-ring. Install the O-ring onto the sensor.
- (b) Install the sensor with the bolt.

Torque: 9.0 N·m (92 kgf·cm, 80 in.-lbf)

4. INSTALL AIR CLEANER ASSY (See page 14-24)