


## POWER SOURCE CIRCUIT (RADIO RECEIVER ASSY)

### CIRCUIT DESCRIPTION

This circuit provides power to the radio receiver assy.

### WIRING DIAGRAM




C

I39184

## INSPECTION PROCEDURE

## 1 INSPECT RADIO RECEIVER ASSY(B, ACC, GND)



- (a) Disconnect the radio receiver assy connector R4.  
 (b) Measure the resistance according to the value in the table below.

**Standard:**

Tester connection	Condition	Specified condition
GND - Body ground	Always	Below 1 $\Omega$

- (c) Measure the voltage according to the values in the table below.

**Standard:**

Tester connection	Condition	Specified condition
B - GND	Always	10 to 14 V
ACC - GND	Ignition SW ACC	10 to 14 V

**NG****REPAIR OR REPLACE HARNESS OR CONNECTOR****OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN DIAGNOSTIC TROUBLE CODE CHART  
 (SEE PAGE 05-1791 )**