


FUEL TANK ASSY (2AZ-FE) COMPONENTS

1111V-01

w/ Rear No. 2 Seat




N·m (kgf·cm, ft·lbf) : Specified torque

P

A92780


w/o Rear No. 2 Seat:



N·m (kgf·cm, ft·lbf) : Specified torque


P

A92781



◆ Non-reusable part_p


A92785



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part


A93064



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A94218



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A94219