


## OVERHAUL

### HINT:

- The installation procedures are the removal procedures in reverse order. However, only installation procedures requiring additional information are included.
- A bolt without a torque specification is shown in the standard bolt chart (see page 03-2 ).




### 1. REMOVE BACK WINDOW PANEL TRIM UPPER

- Using a screwdriver, disengage the 4 clips and remove the trim.

#### HINT:

Tape the screwdriver tip before use.



### 2. REMOVE BACK DOOR TRIM COVER RH

- Using a screwdriver, disengage the 3 clips and remove the trim.


#### HINT:

Tape the screwdriver tip before use.

### 3. REMOVE BACK DOOR TRIM COVER LH

#### HINT:

Use the same procedures described for the RH side.



### 4. REMOVE BACK DOOR TRIM PANEL ASSY

- Remove the assist strap cover.
- Remove the bolt and assist strap.
- Using a screwdriver, disengage the 16 clips and remove the back door trim panel.

#### HINT:

Tape the screwdriver tip before use.

- w/ Rear spoiler:**  
**REMOVE REAR SPOILER (See page 76-8 )**

**6. REMOVE BACK DOOR LOCK ASSY**

- (a) Disconnect the control cable from the outside handle.
- (b) Disconnect the back door cylinder to lock control link from the key cylinder.
- (c) Remove the 3 bolts and the lock control.

**7. REMOVE BACK DOOR LOCK CYLINDER ASSY**

- (a) Remove the 2 bolts and cylinder.

**8. REMOVE BACK DOOR HANDLE ASSY OUTSIDE**

- (a) Remove the 2 nuts and outside handle.

**9. REMOVE LUGGAGE COMPARTMENT DOOR GARNISH SUB-ASSY OUTSIDE (See page 76-13 )****10. INSTALL BACK DOOR HANDLE ASSY OUTSIDE**

- (a) Install the outside handle with the 2 nuts.

**Torque: 5.5 N·m (56 kgf·cm, 49 in·lbf) for B**

**11. INSTALL BACK DOOR LOCK CYLINDER ASSY**

- (a) Install the cylinder with the 2 bolts.

**Torque: 5.5 N·m (56 kgf·cm, 49 in·lbf) for B**

**12. INSTALL BACK DOOR LOCK ASSY**

**Torque: 12.5 N·m (128 kgf·cm, 9 ft·lbf)**