


## RSE SOUND SIGNAL CIRCUIT (MULTI-DISPLAY CONTROLLER SUB-ASSY - RADIO RECEIVER ASSY)

### CIRCUIT DESCRIPTION

The multi-display controller sub-assy sends a sound signal to the radio receiver assy through this circuit. The sound signal that has been sent is amplified by the stereo component amplifier assy, and then is sent to the speaker.



If there is an open or short in the circuit, sound can not be heard from the speaker even if there is no malfunction in the stereo component amplifier assy or speaker.

### WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK HARNESS AND CONNECTOR(MULTI-DISPLAY CONTROLLER SUB-ASSY - RADIO RECEIVER ASSY)



- (a) Disconnect the connectors from the radio receiver assy and multi-display controller sub-assy.
- (b) Measure the resistance according to the values in the table below.

Standard:

Tester connection	Specified condition
R+ - R+	Below 1 Ω
R- - R-	Below 1 Ω
L+ - L+	Below 1 Ω
L- - L-	Below 1 Ω
R+ - Body ground	10 kΩ or higher
R- - Body ground	10 kΩ or higher
L+ - Body ground	10 kΩ or higher
L- - Body ground	10 kΩ or higher

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1632 )