

| | | |
|------------|-----------------|---|
| DTC | B1167/85 | SHORT IN CURTAIN SHIELD SQUIB (LH) CIRCUIT (TO GROUND) |
|------------|-----------------|---|

CIRCUIT DESCRIPTION

The curtain shield squib LH circuit consists of the airbag sensor assy center and the curtain shield airbag assy LH.

The circuit instructs the SRS to deploy when deployment conditions are met.

DTC B1167/85 is recorded when a short to ground is detected in the curtain shield squib LH circuit.


| DTC No. | DTC Detecting Condition | Trouble Area |
|----------|--|---|
| B1167/85 | <ul style="list-style-type: none"> • Short circuit in curtain shield squib LH wire harness (to ground) • Curtain shield squib LH malfunction • Airbag sensor assy malfunction | <ul style="list-style-type: none"> • Curtain shield airbag assy LH (Curtain shield squib LH) • Airbag sensor assy center • Floor wire No.2 |

WIRING DIAGRAM

see page 05-1403 .

INSPECTION PROCEDURE

| | |
|----------|---|
| 1 | CHECK FLOOR WIRE NO.2(CURTAIN SHIELD SQUIB LH CIRCUIT) |
|----------|---|



- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Disconnect the connectors from the airbag sensor assy center and the curtain shield airbag assy LH.
- Measure the resistance according to the value(s) in the table below.

Standard:


| Tester connection | Condition | Specified condition |
|----------------------------|-----------|---------------------|
| C18-1 (ICL+) - Body ground | Always | 1 MΩ or Higher |
| C18-2 (ICL-) - Body ground | Always | 1 MΩ or Higher |

NG

REPAIR OR REPLACE FLOOR WIRE NO.2

OK

2 CHECK AIR BAG SENSOR ASSY CENTER



- (a) Connect the connector to the airbag sensor assy center.
- (b) Using a service wire, connect C18-1 (ICL+) and C18-2 (ICL-) of connector "C".

NOTICE:

- **Twist the end of the service wire in order to insert it into the connector.**
 - **Do not forcibly insert the twisted service wire into the terminals of the connector when connecting.**
- (c) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
 - (d) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
 - (e) Clear the DTCs stored in memory (see page 05-1215).
 - (f) Turn the ignition switch to the LOCK position.
 - (g) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
 - (h) Check the DTCs (see page 05-1215).

OK:

DTC B1167/85 is not output.


HINT:

Codes other than code B1167/85 may be output at this time, but they are not related to this check.

NG

**REPLACE AIR BAG SENSOR ASSY CENTER
(SEE PAGE 60-53)**

OK

3**CHECK CURTAIN SHIELD AIR BAG ASSY LH(CURTAIN SHIELD SQUIB LH)**

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the service wire from connector "C".
- (d) Connect the connector to the curtain shield airbag assy LH.
- (e) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (g) Clear the DTCs stored in memory (see page 05-1215).
- (h) Turn the ignition switch to the LOCK position.
- (i) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (j) Check the DTCs (see page 05-1215).

OK:**DTC B1167/85 is not output.****HINT:**

Codes other than code B1167/85 may be output at this time, but they are not related to this check.

NG

**REPLACE CURTAIN SHIELD AIR BAG ASSY LH
(SEE PAGE 60-38)**

OK**USE SIMULATION METHOD TO CHECK****HINT:**

- Before performing the simulation method, check that the airbag sensor assy center is in check mode (see page 05-1218).
- Perform the simulation method by selecting the check mode with the hand-held tester (see page 05-1218).
- After selecting the check mode, perform the simulation method by wiggling each connector of the air-bag system or driving the vehicle on a city or rough road (see page 05-1218).